

## ADDITIONAL INFORMATION FOR THE USER MANUAL

### DMX channel assignment and function:

#### 2channel mode:

CH1	CH2
<b>Master Dimmer</b> (0-240)	<b>0-4:</b> <b>Blackout</b>
<b>Strobe</b> (241-255)	<b>5-80:</b> <b>Color Micro</b>
	<b>81-150:</b> <b>Color Jump</b>
	<b>151-255:</b> <b>Color Fade</b>

#### 3 channel mode :

CH1	CH2	CH3
<b>RED</b> (0-255)	<b>GREEN</b> (0-255)	<b>BLUE</b> (0-255)

#### 4 channel mode :

CH1	CH2	CH3	CH4
<b>RED</b> (0-255)	<b>GREEN</b> (0-255)	<b>BLUE</b> (0-255)	<b>AMBER</b> (0-255)